

# Remote View Setup Guide


for

## Android Phone






1. Power up the Android Phone.




3. Scroll to find Market.




2. Navigate to the **UP** arrow to pull up All Programs.




4. Navigate to the **Magnifying Glass** to bring up **Search**




5. In the Search Field, type in **Supercam**.



7. Select **Free** to install the application.




6. Select **Supercam** and Continue.




8. Select **OK** to continue.







9. Wait for the application to finish installing.




10. When finish, Navigate back to All Programs.




11. Scroll to find Supercam and launch the application.




12. Input the IP address of the DVR, port number, username, and password.




13. Select Login to log on to the DVR.



15. Once log on, select **Live** to view.



14. Supercam is connecting to the DVR



16. Your Android phone is fully setup to view DVR via Supercam.